

iBind A15

Comb Binding Machine

Plastikbindemaschine

Perforelieuse à peignes plastique

Máquina de canutillo de plástico



Lite Punching Effort **20%**
Lite Punching Sound **LESS**




Max. 15 sheets
blatt
feuilles
hojas



Max. 450 sheets
blatt
feuilles
hojas

iBind A15

Comb Binding Machine
Plastikbindemaschine
Perforelieuse à peignes plastique
Máquina de canutillo de plástico



Waste tray

Binding Guide

Comb	Sheets	Margin	Comb	Sheets	Margin
6mm	25	2	22mm	195	5
8mm	45	2	25mm	220	5
10mm	65	3	28mm	245	5
12mm	95	3	32mm	270	5
14mm	125	4	38mm	320	5
16mm	145	4	45mm	370	5
19mm	155	4	51mm	450	5


General Safeguards

- Place your comb binder on a stable surface.
- Use the machine only for its intended purpose of punching and binding paper and document covers according to the indicated specifications.
- Always test the machine with some scrap paper before punching the final document.
- Take care that there are no staples or such like in the documents to be bound.
- Empty the waste tray regularly.
- Lift the machine from the bottom, not the cover or the handle.
- Unauthorized maintenance is not allowed.

Specifications/Technical data

	iBind Comb Binder A15
Max. Punching Capacity, paper	15 sheets(80 gsm)
Max. Punching Capacity, plastic foils	PVC, 1 sheet, 0.15mm
Punching Margin Control	2mm-5mm
Binding Capacity	Max. comb size, 51mm Max. document, 450 sheets (80gsm)
Max. Width of Paper	DIN A4 (297mm)
Punching Slots	21
Adjustable Edge Guide	A4/A5 - rotary
Net Weight	3.4kgs
Dimensions (H×W×D)	365×280×165 (mm)

Note: Please do not insert a binding comb until you finish punching papers and covers of the required booklet.



(Fig. 1)
Punching preparation: Turn the **Wheel to adjust A4/A5** paper




(Fig. 2)
Punching preparation: Pull the **Punching margin control** from 2mm to 5mm



(Fig. 3)
Push paper(max. 15 sheets of 80gsm at one time) into the **Paper entry**




(Fig. 4)
Pull the **Handle** all the way down until it stops to punch completely through



(Fig. 5)
Insert and open a comb. Pull over the **Comb opening lock** to the "OPEN" position



(Fig. 6)
Load punched sheets directly onto the opened comb



(Fig. 7)
When finished, release the **Comb opening lock** and return the **Handle** to the original position



(Fig. 8)
Remove the bound booklet and enjoy your finished work



(Fig. 9)
Empty the **Waste tray**